

Atmungsaktive Container Membran

Benutzungsanleitung

Fläche um Lüftungsschlitze reinigen

Membrane vom Träger vorsichtig abziehen

Über den Lüftungsbereich kleben und andrücken

Ggf. mit Tuch noch einmal gleichmäßig andrücken

Bitte unbedingt beachten:

Keine Kartonagen od. Waren direkt vor Membran stellen!

Keine scharfen od. spitze Gegenstände an Membran stellen!

Kontakt mit Öl od. Lösungsmittel vermeiden!

Keine hohen Temperaturen in der Nähe der Membran!

Membran bitte nicht abreißen!

Entsorgung wie normale Kunststoffe (gelber Sack)

Breathable Membrane for Container

Instructions

Wipe Container holes with clean rag,

there should be no metal bumps

Peel off their special foil and isolated paper carefully

Paste membrane onto Container holes and press to the wall

Paste membrane around the holes with hand and clean rag

Caution:

Membrane should not be blocked with cartons etc.

Membrane should not be closed to or poked with sharp articles

Membrane should not be contacted with oil or other solvents directly

Membrane should not be contacted with high temperature

Membrane should not be torn

Membrane could be disposed as general plastics after using